

BenQ Joybee 102R

Digital Audio Player



Joybee 102R Quick Start Guide

Joybee 102R 快速使用指南

Joybee 102R 快速使用指南

Joybee 102R Guide de démarrage rapide

Guía de inicio rápido del Joybee 102R

Joybee 102R Guia de iniciação rápida


Joybee 102R - Snelgids

Joybee 102R Handbuch "Erste Schritte"

Guida di consultazione rapida di Joybee 102R

BenQ.com

1




2



4

4.1



①



②




③




④




How to put on the earphones:




Step 1. Stretch the strings aside.



Step 3. Stretch forward the earphones strings.



Step 2. Lay the pad on the back of the neck.



Pull the string down.

How to take the earphones off:

1 Package contents

1. Joybee 102R digital audio player
2. USB cable
3. Wearable earphones
4. Joybee 102R CD-ROM
5. Joybee 102R Quick Start Guide

2 Joybee 102R part features

1. Strap hole
2. Volume up
3. Volume down
4. LED indicator
5. Earphones jack & USB port
6. Power on and play/Stop and power off/Forward
7. Rewind

3 Before using your Joybee 102R

1. Avoid exposing your Joybee 102R to places / conditions of excessive temperatures or of humidity.
2. Avoid any exterior shock or damage to your Joybee 102R.
3. Do not plug anything not belonging to Joybee 102R package content or its accessories to your Joybee 102R port.

4 Initiating your Joybee 102R**1. Charging the battery**

Joybee 102R battery charges by USB cable. Connect Joybee 102R to your computer USB port and Joybee 102R starts charging automatically. When charging completes, green LED will appear.

* It takes about three hours for the first charging.

Note that the computer is supposed to be powered on instead of being idle or power off.

During file transfer, Joybee 102R LED flashes. Please do not disconnect Joybee 102 from pc.

2. Installing QMusic

- ① Before installing QMusic, make sure both Microsoft Media Player 9 and Direct X 8.1 or higher are required. You can find all the software in Joybee 102R CD ROM.
- ② When QMusic installation completes, you will see a shortcut on your desktop.



Note that if you are using Joybee 102R as flash disc in Windows 98 SE, you have to install driver in Joybee 102R CD ROM first.


5 Storing music into your Joybee 102R**1. Converting your CD sound tracks into MP3 format.**

- ① Insert CD in your computer. QMusic will search the album database automatically if your computer is connected to the Internet.
- ② Check to choose the songs you want to convert to MP3 format, and press ⑤ to start conversion. These MP3 files would be put in the new album directory under My Joybee in Music Library.
- ③ When finished, you can drag them directly to your Joybee 102R.

2. Save your download MP3 songs in PC hard drive into your Joybee 102R.

- ④ Click on Joybee 102R and click ⑥.
- ⑤ Locate where your MP3 audio files are, select the files and click "Open."

You must transfer *.wma files with DRM to Joybee 102R with Microsoft Media Player 9.0; otherwise, these files can not be played by Joybee 102R.

6 Basic How-To

1. Press to volume up during playback.
2. Press to volume down during playback.
3. During playback, press to play the previous track.
4. A. Long press to turn Joybee 102R on when the earphones are connected to phone jack. Music will start to play immediately. LED flashes green during the playback.
B. During playback, press to play the next track.
C. Long press to turn Joybee 102R off. Joybee 102R will turn off immediately.

Note that Joybee 102R can not be powered on if the earphones are not connected to it.

- * Joybee 102R will flash red and turn off automatically when earphones are plugged off.
- * To solve any possible malfunction problem, please plug the earphones off first, press power button to reset, and then follow the steps above to re-power on Joybee 102R.
- * WMA DRM stands for Microsoft Windows Media Digital Rights Management, which provides secure files distribution and ease of use.